LR5011 TEMPERATURE LOGGER

Operation Manual

June 2013 Revised edition 2 Printed in Japan LR5011B981-02 13-06H



Thank you for purchasing the HIOKI LR5011 Temperature Logger.

This guide introduces the logger's basic measurement procedure to first-time users.

Before using the instrument, be sure to read the Instruc-



Read First


Confirmation

Confirm package contents, and prepare needed items.

Logger and Accessories



LR6 alkaline battery (Pre-installed in the log-



Stand This is the logger stand. See the Instruction Manual for details

Instruction manual

Refer to this manual for

operating procedure

details, or when problems occur


Option



LR5091 Communication Adapter (Includes LR5000 Utility Program CD [PC application software] and

USB Cable)

■ Importing data to a computer requires the optional LR5091 Communication Adapter or LR5092-20 Data Collector



(Please use Hioki-brand options.

Display Example: Setting the

recording interval to 10 minutes

Temperature Sensor

Example: LR9604

3 Settings

Display the settings, and select the setting item.

Configure the setting as needed.



Apply the new setting contents.

(The setting items are displayed as shown under Setting Display



Hold the $\binom{REC}{STOP}$ button for two seconds while recording (while [REC] is displayed).

Note: Continue pressing the button until the [REC] indicator changes from a blinking to off state.

DATA SOCIO

1000

4111

[REC] disappears when recording stops.

If the stop method is set to [OFF], recording stops automatically when memory becomes full.


2 Preparations

Install the battery and connect the cable to the logger.

Installing the Battery

■ Press the PUSH tab as shown, and pull the battery cover back.

Install the battery as



While confirming that there are no gaps, press with vour fingers to close the battery cover.

When the battery is installed, the logger turns on (there is no power switch).



Connecting a Temperature Sensor



Align the triangles on the plug body and in front of the sensor iacks, and insert the plug securely. (Insert the protruded parts of the connecting cable into the holes of the device.)

■ Temperature sensors are available as options. Select according to your application.




Recording

Before recording, install the logger and perform pre-measurement inspection.

(See the Instruction manual for details.)

Start

DATA



From the Measurement display, hold the

 $\binom{\text{REC}}{\text{STOP}}$ button for two seconds.

Note: Continue pressing the button until the [REC] indicator changes from a blinking to on state.


When the blinking stops and the data count is zeroed, recording starts.

After one second, the measurement display reappears.


- Logger memory contains the data for two recording sessions. (Be aware that old data is erased when starting recording after two record-
- Data can be imported to a computer without stopping recording.



Setting Display



Measuring Display



Battery life is extended when on (enabled). Default is on.

■ Recording Mode

When on (statistical recording), instantaneous, maximum, minimum, and average values are recorded at each interval. (Record statistical values) Battery life is shorter.

Default is off.

■ Stop Method

Select what happens when memory becomes full.

When on, the oldest data is overwritten (Endless Recording), and when off, recording stops (One-Time Recording).

Default is on.



Operating Buttons

REC/STOP

Displays settings

and time, etc.)

Recording in progress

Stop method enabled

Recorded data count

Recording mode enabled

Maximum and minimum values

ENDLESS

MAX. MIN

DATA

Upper/lower threshold exceeded

Changes Measurement display contents.

Changes setting values on the Settings display.

Hold for two seconds to start/stop recording.

ues, recorded data count, etc.)

From a setting display, switches to measurement display.

■ Setting Display: Displays settings (recording interval, date

■ Measuring Display: Displays recorded data (measured val-

Indicators










Battery Status Indicator

REC AL ENDLESS STAT FILT





Is the sensor plug inserted all the way in?

measures, the sensor and logger need to be DATA inspected and repaired.

Verify the correct plug orientation, and insert it as

Please contact your dealer or Hioki representative.

Note: The maximum and minimum values are not displayed when the recorded data count is 0.

Troubleshooting

■ The display is blank.

Press any button or send a communication signal to turn on the display.

been stopped.

Is the stop method disabled (set to OFF)?

With disabled, recording stops automatically when memory becomes full. stop method.

(In this case, old data is overwritten when the memory becomes full.)

■ Recorded data has disappeared.

(The logger retains the data from both current and most recent prior recording operations.)


■ To erase logger memory

Erase using the PC Utility program. See the Instruction manual for details.

■ The battery is depleted too quickly.

Are you using a zinc-manganese battery?

Install a new AA-size (LR6) alkaline battery.



Is auto power saving enabled (set to ON)?

When enabled, the display blanks after 30 seconds of operator inactivity.

■ The [REC] indicator disappears even though recording has not

To record continuously until stopped by the REC/STOP button, enable the

Does recording restart after stopping?


Note that if recording is accidentally restarted after stopping, data recorded prior to the last recording is automatically erased.

Are you using the battery originally supplied with the logger?

5 Importing and Displaying Data on a Computer

Installing the PC Application Program

> Required Items: Supplied CD (for Windows XP) LR5091 Communication Adapter, USB cable



3



■ LR5000 Utility Program Operating Requirements

• CPU 1 GHz or faster processor clock

• RAM At least 512 MB

• os Windows XP SP2 or later Windows Vista SP1 or later

Windows 7

 Library .NET Framework 2.0/3.5

Interface

• Monitor Resolution 1024 x 768 or higher

 Hard Disk At least 30 MB free space

(Additional space is required for storing recorded data. Another 500 MB may be required if .NET Framework 2.0 or 3.5 is not yet installed.)

■ What if the PC Utility program cannot be installed?

- · Be sure that the computer meets the above operating require-
- Carefully read "Installing the PC Application Program" in the Instruction manual, and reinstall. Pay special attention to the
- 1. Be sure to log in using an Administrator account.
- 2. Before installing, be sure to close any programs running on

2 Starting the PC Utility Program


From the Windows [Start] menu, select [All Programs]-[HIOKI]-[LR5000 Utility [LR5000 Utility] to start the program.

The program starts automatically from the next Windows logon, and the icon appears in the task tray (notification area)



Importing (Saving) Recorded Data to a Computer, and Graph Display

Required Items: LR5091 or LR5092-20 and supplied USB cable



Company Compan Acquisition Stop

Data importing Data is saved to pegins automatically a file

The viewer starts up automatically with a graph displayed

PC Utility Program Features



Making Detailed Settings

Configure settings on the LR5000 "Data Logger" series loggers, and on the LR5092-20 Data Collector.


The PC utility program can access settings that cannot be accessed from the logger itself.

For example,

■ Set recording start/stop method and timing to start and stop recording automatically at scheduled times (Timer Measure-



■ Measurement data can be freely scaled for display (Scaling).



- Set upper and lower thresholds so that measurements outside of the range cause [AL] (Alarm) to appear on the logger screen (Alarm Judgment).
- Add comments to measurement data.



Processing Recorded Data

Process data imported to the computer.

- Freely scale for display (Scaling)
- Calculate electric power easily (using clamp logger measurement
- Calculate energy cost easily (using clamp logger measurement values)
- Calculate duty cycle
- Calculate dew-point temperature (using temperature/humidity logger measurement values)



Organizing Recorded Data

Sort data imported to the computer.


- Copy (files between folders)
- Move (selected files between folders)
- Delete (selected files)
- **■** Combine

(multiple recording files into one, and save with new file name)

(data for a specified period, and save with new file name)




Displaying Recorded Data in a Table





Printing Recorded Data

Example Graph Printout



■ See the Instruction manual for details.

