


Semi-Automatic Scale Screen Printing Machinery For Scales(GW-2030-R1)



| | |
|-----------------|--------------------------|
| Model number: | GW-2030-R1 |
| Printing area: | 200*300mm |
| Printing speed: | 2500PCS/Hr |
| Machine size: | 1000*1150*1450mm |
| Gross weight: | 150kg |
| MOQ: | 1set |
| Payment terms: | T/T,Western Union,Paypal |
| Package way: | plywood |
| Delivery way: | by sea |
| Lead time: | within 10 workdays |
| Worktable size: | 250*450mm |



Enquiry



Back

Describe

Automatic plastic ruler screen printing equipment with rotary table

Application

This kind machine is high precision rulers screen printing machine,with high speed rotary worktable,can run in high speed without any vibrations.During printing process,you can put or take off the products,reduce machine down time.Max.printing speed can be up to 2500PCS/Hr,mainly applied to printing rulers, equilateral triangles rulers, Delta rulers, Protractor etc stationery products in large quantities

Function:

- 1.Speed cam splitter architecture rotary worktable
- 2.Adopts Taiwan LSK linear Guide, assure the machine with high precision
- 3.Worktable can be adjusted slightly, you can adjust on X.Y direction, adjustment precision up to 0.01MM
- 4.High strength large capacity vacuum tube adsorption
- 5.Various stationery rules does not require making jigs, quick change
- 6.No product,no print
- 7.LCD control panel, multiple print mode selection, operation is simple and convenient
- 8.Full-cast aluminum body, metallic paint
9. Left and right stroke can be adjustable,Taiwan Photoelectric switch limit
- 10.Squeegee/blade angle can be adjusted freely
11. Screen frame position can be adjusted front and back ,left and right,up and down
12. Up and down,Left and right are equipped with Taiwan CEC oil buffer to eliminate printing vibrations
13. The whole machine runs fastly, smooth, noiseless

Technical Parameter

Max.printing area:200*300mm
Max.printing speed:2500PCS/Hr
Worktable size:250*450mm
Max.frame size:300*500mm
Left and right stroke:350mm
Up and down stroke:100mm
Disc size: 600mm
Workpiece max.height: 50mm
Power:220V 50-60Hz
Machine size: 1000*1150*1450MM
Weight:150kgs
Rotary workstation: 2,4,8(optional)

Note: This kind machine is Suitable for 30CM or less than 30CM triangle ruler, ruler, Protractor and related flat-product LOGO printing