

Flat Bed Screen Printing Machine(GW-4060)



Model number: GW-4060

Printing area: 400*600 MM

Printing speed: 1000 pieces per hour

Machine size: 800*700*1300MM

Gross weight: 490KGS

MOQ: 1 set

Payment terms: T/T,western union, paypal

Package way: plywood

Delivery way: by sea or by air

Lead time: within 7days

Worktable size: 500*700 mm



Enquiry



Back

Describe

Wedding card Screen printing machine

Application:

the flat bed silk screen printing machine is suitable for printing some flat items which size is within 400*600 mm,such as paper,PVC sheet,plastic film,textile,keyboard,circuit board ,CD disk,plastic box ,ruler etc.

Function:

1. PLC coordinating soft-touch panel compile programmes
2. Auto 4-digit counter built-in
3. kinds of printing cycle designed by printing action, you can be free to choose according to your printing craftwork.
4. Airframe adopts coin alloy,and metal coating surface
5. distyle vertical constructure, high precision, steady operation
6. installing scraper constant pressure equipment
to make sure pressure is steady when printing
7. the angle of scraper and reclaim blade can be adjusted randomly
8. you can regulate work-table back and forth or right and left, and then fastening it
9. you can regulate screen frame back and forth, right and left or level orientation
10. printing head can be liftuped, that is convenient to pick-and-place sreen frame
11. adopting Germany ORIGA roldless cylinder to drive transversa moving, TaiWai Ruike electronic switch to drive transversa stroke
12. finished and high-strength hard work-table with even suctionhole and high vacsorb, that can make sure overprinting accuratelly.
13. installing scrambling device on work-table, in order to avoid injuring hands
14. installing Taiwan CEC absorbers to removing shaken
15. The machine is running fastly,it is steady and low voice

Technical parameter:

- 1.Max.printing area:400*600mm
- 2.Max.printing speed:1000PCS/Hr
- 3.Power:220V/110V 50-60MHZ
- 4.Air pressure:5-7bar
- 5.Worktable size:500*700mm
- 6.Max.workpiece height:50mm