

4 Color Flat Bed Automatic Screen Printing Machine(GW-4F-UV)



Model number:	GW-4F-UV
Printing area:	300*200 MM
Printing speed:	2100 pieces per hour
Machine size:	2000mm*1420mm*1750mm
Gross weight:	1000 kgs
MOQ:	1 set
Payment terms:	T/T,Western Union,Paypal,L/C
Package way:	plywood
Delivery way:	by sea or by air
Lead time:	within 20days



Enquiry



Back

Describe

4 Color Flat Bed pvc sheet Screen Printing Machine

The machine can print mass single to multicolor flat product,such as square,rectangle.board,
The new transmission system consisted of advanced imported motor,speed converter device and pneumatic component which has the function of electrodeless variable-speed,synchronous transmission ,auto allocation and no-work piece-no -printing.

Main function of this machine:

- ⊕ Auto feeder
- ⊕ Automatic loading direction-selectionsystem
- ⊕ Auto flame treatment for container surface
- ⊕ Electrodeless variable-speed motor system
- ⊕ Adjustable mechanical synchronous transfer system
- ⊕ Auto pre-allocation system
- ⊕ UV-coating system

Main parts:

- ⊕ Machine main motor:MOTOVARIO
- ⊕ PLC:OMRON
- ⊕ Photoelectric switch:OMRON
- ⊕ Touch screen:KINCO
- ⊕ Button switch:APT
- ⊕ Contactor:SCHNEIDER
- ⊕ Relay: OMRON
- ⊕ Frequency converter: PANASONIC
- ⊕ UV coating system:HONOVIA
- ⊕ Pneumatic components:SMC/AIRTAC

Technical parameter:

- printing area of product:L300mm*W200mm*H200mm
- printing speed:2100pcs/hour
- electric:3P AC 380V 50/60Hz
- power:7.5KW
- air compress:6~8bar
- size of machine:2000mm*1420mm*1750mm
- net weight:1000 kg