

High Rapid Rotary Screen Printing Machine For T-shirt Tagless



Model number:	GW-100TRS
Printing area:	130*100MM
Printing speed:	2000pcs/Hr
Machine size:	1000*920*1450mm
Gross weight:	90kg
MOQ:	1set
Payment terms:	T/T,Western Union,Paypal
Package way:	plywood
Delivery way:	by sea or by air
Lead time:	within 30 workdays



Enquiry



Back

Describe

Video

Anti Slip Soccer Socks Rapid Single Color Silk Screen Printing Machine

Application:

high rapid tagless/label screen printer in textile industry,the speed can be up to 2000PCS/Hr,it is suitable for printing garment tagless or label,rotary worktable,very convenient to load or unload products,lots of customers like it very much because of high quality and low price

Function:

- 1.PLC controlled,user friendly interface,clear function display and easy operation
- 2.Flat screen printing with infrared drying system.Suitable for different types of ink and small area screen frame printing such as T-shirt collar
- 3.Five station driven by step motor to insure stable and smooth running
- 4.Angle and height of squeegee and flood blade can be adjusted to insure consistent printing pressure
- 5.Adopts 5 stations rotary worktable,one for substrate loading and one for printing,two for drying and one for substrate unloading and five stations working simultaneously
- 6.With one cycle and auto function and switch easy

Technical parameter:

- 1.Max.printing area:130*100mm
- 2.Printing speed: 2000PCS/Hr
- 3.Power:3.2KW
- 4.Machine size:1000*920*1450mm
- 5.Weight: 90kgs
- 6.Workstaion: 5 pieces
- 7.Drying system: 2 set

Related Posts

Next Product: Non Slip Gloves Screen Printing Machine(GW-100TRS-G)

Prev Product: None