

Automatic 2 Color Screen Printer For Can Coolers(GW-200TRS-C)



Model number: GW-200TRS-C

Printing area: 130*100mm

Printing speed: 1200PCS/Hr

Machine size: 1350*1450*1600mm

Gross weight: 210kgs

MOQ: 1set

Payment terms: T/T,Western Union

Package way: plywood

Delivery way: by sea or by air

Lead time: within 15 workdays



Enquiry



Back

Describe

Video

Knitted Technics and Adults Age Group screen printing machine for socks and gloves

Application:

this high rapid tagless/label screen printing machine is specially designed for printing can coolers,koozies.automatic screen printing machine,its printing process like below

load the koozies on the machine by hand---auto printing--auto drying--180degree ratory--then print another side--auto drying--auto unloading

easy to operate and low price

Function:

- 1.PLC controlled,user friendly interface,clear function display and easy operation
- 2.Flat screen printing with infrared drying system.Suitable for different types of ink and small area screen frame printing such as koozies
- 3.Eeight station driven by step motor to insure stable and smooth running
- 4.Angle and height of squeegee and flood blade can be adjusted to insure consistent printing pressure
- 5.Adopts 8 stations rotary worktable,one for substrate loading and one for printing,two for drying and one for substrate unloading and five stations working simultaneously
- 6.With one cycle and auto function and switch easy.

Technical parameter:

- 1.Max.printing area:130*100mm
- 2.Printing speed: 1200PCS/Hr
- 3.Power:2.5KW
- 4.Machine size:1350*1450*1600mm
- 5.Weight: 210kgs
- 6.Workstaion: 8 pieces
- 7.Drying system: 2 pieces