


3 Colors Gloves Screen Printing Machine(GW-300TRS-G)



Model number:	GW-300TRS-G
Printing area:	200*300mm
Printing speed:	700pairs/Hr
Machine size:	1750*1650*1550mm
Gross weight:	380kgs
MOQ:	1set
Payment terms:	T/T or Western Union,or Paypal
Package way:	plywood box
Delivery way:	By Ocean
Lead time:	within 15 workdays after your order confirmation



Enquiry



Back

Describe Video

3 Colors Gloves Screen Printing Machine(GW-300TRS-G)

Application:	high rapid tagless/label screen printer in textile industry,it is suitable for printing garment tagless,gloves or label,rotary worktable,very convenient to load or unload products,lots of customers like it very much because of high quality and low price
Configuration instructions:	1.Machine control part adopts MITSUBISHI PLC controller,Touch screen control,easy to operate 2. Three printing model to choose,manual/semi-auto/full-auto,printing Interval time is numerical control 3. The rotate worktable adopts electric controll,CHINT AC contactor, Taiwan FOTEK photoswitch 4. Drying system lamp brightness can be adjusted,like this,it can meet different temperatures needing 5. High quality infrared lamps,it can be up to 1500-2000 hours 6. It has "No product,No print" function,you can open and stop machine freely during printing,Product sensors can be 360 degrees adjustable 7. It has total 8 pcs of work station,3 pcs of printing work stations,3 pcs of drying systems and 2 pcs of load/discharging work stations 8. The 3 printing head can be controlled independently 9. Pneumatic components control adopts Taiwan brand,front and back printing precision linear Guide rails using Taiwan brand. 10.Machine surface is metallic paint ,beautiful and dignified
Technical parameter:	1. Printing area: 200*300mm 2. Frame size: 420*480mm 3. Machine size: 1750*1650*1550mm 4. Printing speed: 700 pairs/Hr (it can print 1 pair per time) 5. work station: 8PCS 6. Drying system: 3PCS 7. Machine weight: 380KG
Samples	