

## Desktop Single Color Screen Printing Machine With 4 Stations(GW-2030RS-1)



Model number: GW-2030RS-1

Printing area: 100\*200MM

Printing speed: 1500PCS/Hr

Machine size: 80\*74\*110cm

Gross weight: 150kgs

MOQ: 1set

Payment terms: T/T,Paypal or Western Union

Package way: plywood

Delivery way: by Ocean or By air

Lead time: within 7 workdays

Worktable size: 130\*230mm



Enquiry



Back

Describe

Images

### MINI desktop screen printing machine for PCB board and toys

#### Application:

This is tabletop screen printing machine, special design for high speed, high precision screen printing. It adopted Mechanical from cam separator TAIWAN to make rotary table. It can rotate quickly without shock. You can upload and download products when printing, that can reduce the stop time of machine. The max printing speed can be up to 1500pcs/hr. It's very suitable for big quantity screen printing.

#### Function:

#### Specifications:

1. IC with touch panel program action programming;
2. Aluminum casting body with metal coating;
3. Auto 4-digit counter, calculate printing quantity;
4. Double pillar up/down structure, making sure precision and stable;
5. Transverse stroke can be adjusted, using Taiwan sensor to limit;
6. Squeegee, flood bar can set as any angle;
7. Squeegee constant pressure, keeping printing pressure stable;
8. T-slot worktable, convenient to install jig;
9. Installing CEC buffer, making sure printing stable;
10. Action mode: Auto semi-auto manual;
11. Start up: Panel pedal;
12. Squeegee pressure control: Pressure regulating valve;
13. Vertical driven: Pneumatic;
14. Transverse driven: Electronic;
15. Max printing area: 100\*200mm;
16. Worktable size: 130\*230mm;
17. Transverse stroke: 400mm;
18. Vertical stroke: 100mm;
19. Rotary table diameter: 450mm;
20. Max height of product: 50mm;
21. Rotary table workstations: 2PCS 4PCS