

Screen Printing Machine For Bottles(GW-4A)



Model number: GW-4A

Printing area: 590*200mm

Printing speed: 1000PCS/Hr

Machine size: 1000x720x1250mm

Gross weight: 240kg

MOQ: 1set

Payment terms: T/T,Paypal,Western Union,L/C

Package way: plywood

Delivery way: by sea or by air

Lead time: within 7 workdays



Enquiry



Back

Describe

Semi-automatic one color magic glass bottle silk screen printing machine

Function:

- 1.All function is controlled by Mico-computer,high quality and easy operation
- 2.4-digit automatic counter built-in
3. Having the function of printing cylindric or taper object
- 4.Both printing stroke and speed are adjustable that meets different printing requirement
- 5.Worktable adjustable on up/down,left/right and plane angle,easy and fast adjustment to achieve high printing precision
- 6.Pneumatic printing controlled and equipped with pressure adjustment system
- 7.The machine is controlled by mico-computer which is stability and reliability
- 8.Clear bright blue display,can display work estate of the machine at any moment
- 9.High-quality AUTONICS sensor and perfect fault alarm system
- 10.Convenient food switch,easy operation and maintained convenience
- 11.Light and steady aluminum alloy parts and import of enduring bearings and axle sleeves
- 12.International famous pneumatic units such us SMC,FESTO and so on
- 13.Independently printing and ink covering speed controll

Technical parameter:

- 1.Max.workpiece diameter:≤175mm
- 2.Max.workpiece length:≤250mm
- 3.Printing entire circle diameter:≤120mm
- 4.Max.Printing speed:1200pcs/hour
- 5.Power:110/220V 60/50Hz 50VA
- 6.Air consumption :56Litre/min(6bar)
- 7.Out dimension:1000x720x1250mm
8. Weight:240kg