

# Automatic One Color Cylinder Screen Printing Machines(GW-1A-UV)



Model number:	GW-1C-UV
Printing speed:	4200pcs/hour
Machine size:	L2000mm*W1200mm*H1750mm
Gross weight:	1600KG
MOQ:	1 set
Payment terms:	T/T 40% deposit,remain T/T before shipment or LC at sight
Package way:	wooden box
Delivery way:	by sea
Lead time:	within 25 workdays



Enquiry



Back

## Describe

### Full Automatic rotary screen printing machine for plastic bottle printing

#### Application:

It is suitable for printing some round and oval containers,such as cosmetic,leechdom and food service industry. It can print kinds of design on the surface of round/oval container.The material of workpiece can be plastic,glass,ceramic,metal and so on

#### Main function:

- ⊕ Auto feeder
- ⊕ Automatic loading direction-selectionsystem
- ⊕ Auto flame treatment for container surface
- ⊕ Electrodeless variable-speed motor syst
- ⊕ Adjustable mechanical synchronous transfer system
- ⊕ Auto pre-allocation system
- ⊕ No printing while no bottle system
- ⊕ UV-coating system

#### Technical Parameter:

- ⊕ Round printing diameter:25mm~110mm
- ⊕ Round printing height:60mm~280mm
- ⊕ Oval printing diameter:R35mm~R180mm
- ⊕ Oval printing height:60mm~280mm
- ⊕ Max printing speed:4200Pcs/Hour
- ⊕ Power supply:AC220V 1 PAHSE/AC380V 3Phase 50Hz/60Hz
- ⊕ Rated power: 7KW 20A
- ⊕ Air pressure:5~8bar
- ⊕ Machine dimension:(L2000mm\*W1200mm\*H1750mm)
- ⊕ Machine weight:1600kg