

Professional Balloon Screen Printing Machine With Rotary Worktable

Manufacturers



Model number: GW-BL-B

Printing area: 150*150mm

Printing speed: 700pcs/hour

Machine size: 1150*800*1440mm

Gross weight: 160kgs

MOQ: 1set

Payment terms: T/T,Western Union,Paypal,L/C

Package way: plywood case

Delivery way: by sea or by air

Lead time: Within 25 workdays

Worktable size: 150*150mm



Enquiry



Back

Describe

Balloon Printing Machine,automtaic balloon screen printing machine 1 Color print

Application:

With advantages of high quality,working steady,easy to install and operate and high precision.

This kind machine is with 8 worktables,very easy to load and unloading balloons.

Technical Parameter:

- 1) Max.printing area: 150*150mm
- 2) Max.screen frame size: 250*380mm
- 3) Max.printing speed: 800-1000PCS/Hr
- 4) Power: 220V 50Hz
- 5) Machine size: 1150*800*1400mm

Features:

- 1) Automatic blowing function with non balloon non-blowing function
- 2) Automatic printing head with non balloon non-printing function
- 3) Automatic unloading with non balloon non-unloading
- 4) Air blowing pressure independent control, air pressure adjustable
- 5) Balloon automatic rotation with non balloon non-rotation, can print 2 side of balloon
- 6) Machine every actions can be control independently, Convenient debugging machine