

Big Format 2 Color Pad Printer For Lighter(GW-M2/S)



Model number: GW-M2S

Printing area: 80*160MM

Printing speed: 1500 pieces per hour

Machine size: 1000*650*1500MM

Gross weight: 195KGS

MOQ: 1 set

Payment terms: T/T,Western Union,Paypal,L/C

Package way: plywood

Delivery way: by sea or by air

Lead time: within 7days



Enquiry



Back

Describe

Two Color Semi Auto mouse pad , flash disk Pad Printer With Automatic Pad

Cleaning

Application

The pad printing machine is for big size workpiece,automatic color registration,two time printing can complete one printing circle,so efficiency is low but easy operation, and just need one clamp.Suitable for products:electrical appliances,cups,barrel,stationary,gifts,pen, promotional gift,keychains,ring,lighter, toy car, and so on

Function

1. Professional manufacturing experience,the produce are update and improve constantly,quality is excellence
2. Printing speed and environmental quiet is the first-class in the same line,and other design performance are in a peor-leading position
- 3.programmable control panel,flexible and reliable procedure,Adopts Japanese SMC pneumatic and electronic units,and also use harden bearings and defend from famous factory
4. Unique advantage,the head of machine can be adjusted and convenient to replace ink,pads,steel plate and parts,ink tray and printing size.Special design ink cuo and ink tray can use each other.at the same time,the ink up independent base can be adjusted X.Y direction,easy to do color registration,improve produce efficiency
5. All the machine is with security plate and cut emergency power system,meet international safety standard

Technical parameter

1. Steel plate size:100*200mm
2. Printing color:2 colors
3. Max.printing speed:1200PCS/Hr
4. Frequency:50-60HZ
5. Net weight:200kg
6. Power:110/220v
7. Air pressure:5-7bar