

## High Speed 2 Color Pad Printer For Pen(GW-M2/C)



Model number:	GW-M2C
Printing area:	80*160MM
Printing speed:	2100 pieces per hour
Machine size:	1200*960*1500mm
Gross weight:	225kgs
MOQ:	1 set
Payment terms:	T/T,western union, paypal
Package way:	plywood
Delivery way:	by sea or by air or by express
Lead time:	within 7days



Enquiry



Back

### Describe

#### Application:

this pad printer is with conveyor worktable,products can be double-color pad printing continuously,one circle can complete one color register ,compare with pad printer with shuttle ,the speed is very fast .bigger steel plate can carry out double -color register for big image ,high speed ,running steady ,it is suitable for printing electronic product plastic shell, hardware product ,stationery,logo on the surface of small arts ,USB,SM card, promotional gift,and crafts and so on .

#### Advantage of pad printer :

- 1.SCM IC compile action program ,kinds of printing model options .
- 2.Auto 4-digit counter built -in ,and stat ,printing quantity .
- 3.Airframe adopts coin alloy ,and metal coating surface.
- 4.Worktable ,plastic head and ink tray can be adjusted X, Y, Z direction.
- 5.Sucking ink and the pressure of printing pad can be adjusted independently.
- 6.The distance of scratching ink is adjustable .
- 7.It has function of leveling ink by sliding automatically on front /back ,this can avoid printing ink partial solidification.
- 8.The speed of all the cylinders have an independent regulator intortum.
- 9.Adopts original Japan SMC and Taiwan MINDMAN pneumatic component .
- 10.Each adjustable lacion has scale logo.
- 11.when there is no pressure air into ,it has prohibition of plastic head Down functio .
- 12.The machine is running fastly ,it is steady and low voice .
- 13.it has automatic cold wind system .

#### Technical parameter:

Steel plate:100\*200mm  
Printing speed :1500PCS/Hr  
Power :220V 50-60MHZ/1000W  
Air pressure:5-7bar  
Max printing area:80\*130mm  
Printing workstation :8pcs  
Printing color :2colors  
Machine size:1200\*960\*1500mm  
Net weight: 225KG