

Automatic Two Color Pad Printer With Touch Screen(GW-P2S-ST)



Model number:	GW-P2S-ST
Printing area:	80*80MM
Printing speed:	1200 pieces per hour
Machine size:	1300×900×1520mm
Gross weight:	160kgs
MOQ:	1 set
Payment terms:	T/T,western union, paypal
Package way:	plywood
Delivery way:	by sea or by air
Lead time:	within 10days



Enquiry



Back

Describe

2 Color PVC Sheet , Plastic shell Pad Printing Machine For Sale

Application:

Big double-color pad printer with shuttle, bigger steel plate and central distance between ink tray , can carry out double-color register for big image,conveniently adjustable,running steady, it is suitable for printing electronic product,plastic shell,hardware product,stationery,logo on the surface of small arts and crafts and so on.

Function:

- 1.Touch screen controls
- 2.Auto 4-digit counter built-in,and stat. Printing quantity
- 3.Airframe adopts coin alloy,and metal coating surface
- 4.Worktable,plastic head and ink tray can be adjusted X.Y.Z direction
- 5.Sucking ink and the pressure of printing pad can be adjusted independently .
- 6.The distance of scratching ink is adjustable
- 7.It has function of leveling ink by sliding automatically on front /back,this can avoid printing ink partial solidification
- 8.The speed of all the cylinders have an independent regulator intortum
- 9.Adopts original Japan SMC and Taiwan MINDMAN pneumatic component
- 10.Each adjustable location has scale logo
- 11.Unique machine body hold-up design,conveniently adjust machine and change steel plate
- 12.when there is no pressure air into ,it has prohibition of plastic head Down function
- 13..The machine is running fastly,it is steady and low voice
- 14.it can be instead of single color double-head pad printer when shuttle table is not running
- 15.with automatic head cleaning system.

Technical parameter:

- 1.Steel plate size:100*250mm
- 2.Closed ink cup size: 90MM
- 3.Max.printing speed:1000-1200PCS/Hr
- 4.Power:220V or 110V
- 5.Printing workstation: 1PC
- 7.Package dimension(LXWXH): 1300×900×1520mm
- 8.Gross weight:155KG