

1 Color Pad Printer For Printing Rulers(GW-RUL-100)

Zoom



Model number: GW-RUL-100

Printing area: 80*1100MM

Printing speed: 500PCS/Hr


Gross weight: 250kgs

MOQ: 1set

Payment terms: T/T or Western Union or Paypal

Package way: Plywood

Lead time: within 15 workdays



Enquiry



Back

Describe

1 Meter Steel Ruler Pad Printing Machine 1 Color Tampon Printing Machine

Application:

The ruler pad printer is special design for printing ruler with 1m length. It's adopted transverse ink cup system, double printing cylindrical to make sure enough pressure

Function:

1. Compoile proorammina by IC. easv to operate;
2. Pad printing with single color, perfect printing quality;
3. Stable function, printing speed: 500times / hr;
4. Suitable ruler length: Within 100CM;
5. Sealed ink cup system, more environmental;
6. Locating by keeping one side with big vacuum function;
7. Using SMC (Japan) and Taiwan pneumatic parts;
8. The X and Y of printing pad can be adjusted;
9. It's suitable for printing kinds of aluminum ruler, plastic ruler, wooden ruler within 100CM.

Technical parameter:

Steel plate size: 100*1200mm

Ink cup diameter: 90mm

Printing speed: 500PCS/hr

Power:110V or 220V(optional)

Air pressure: 5-7bar