



- Location :
- [Home](#)
- > [Product](#)
- > [Mechanical experimental equipment](#)
- > [Fatigue testing machine](#)



Headphone folding life testing machine L-EJZD01

Release date : 2020-06-03

- [Home](#)
- [About Us](#)
- [Details](#)



1. 耳机折叠寿命试验机用途简介

耳机折叠寿命试验机 模拟用户使用过程中，耳机摇摆前后摆动的操作。耳机的听筒部分被固定在夹具上（耳机部分固定另一个夹具上）→打开摆臂拨动耳机打开到一定角度停止，→闭合摆臂拨动耳机闭合到一定角度停止，传感器检测并记数

2. 耳机折叠寿命试验机主要参数

- *工位数量：3 个工位/台
- *操作方式：按键式
- *动作执行组件：AC 电机
- *摆臂角度范围：1~180 度（可设定）
- *计数器：0-999999 次（可设定）
- *电压：220V； 功率：500W（含电机）
- *重量：30kg
- *外形尺寸：1200mm×550mm×800mm；

Recommended

•



Automatic tool metallographic measuring instrument V400

•



Automatic tool metallographic measuring instrument V800

•



Automatic tool metallographic measuring instrument V1800

•



Automatic tool metallographic measuring instrument V2000

GUANGDONG JINUOSH TECHNOLOGY CO.,
LTD

Building 28, Guanghui Industrial Zone, Dongke Road, Dongcheng District, Dongguan City,
Guangdong Province 0769-2282-0867

•

•

•

•

•

GUANGDONG JINUOSH TECHNOLOGY CO., LTD All rights reserved Company address: Building 28,
Guanghui Industrial Zone, Dongke Road, Dongcheng District, Dongguan City, Guangdong
Province Service Hotline: 188-9871-9887 0769-22820867

[Home](#)

[Product](#)

[Map](#)

[About us](#)