

Click to shoot, Clip-on or handheld.
Clip Series Precooled
Thermal Imaging Attachment
[Click here more information](#)
[Wants Global Distributors](#)

Meet Clip C Series

The Clip C Series is designed as an attachment for any type of the standard day scope.
NO REZEROING is needed just CLAMP&SHOOT.

It is a dual-use camera since it can be switched into a professional monocular with the standard delivered eyepiece in few seconds.
Now expanding your detection ability together with your day-scope.



Clip on thermal rifle scopes are truly versatile thermal imaging scopes that give you increased options and functionality. Whether you are looking to use it as a dedicated thermal scope or clipped on in front of your day optics for increased thermal imaging zoom capability, these scopes can easily accommodate your needs. Our clip on's fit any Picatinny rail mount in seconds, and there's no need to re-zero. So if you're in the hunting realm, you can switch to your favorite aiming method with ease. These scopes need absolutely no light to function, so you can literally turn any day scope into a night vision scope with a simple throw lever mount. Now you can see your targets any time of day or night making it a truly robust aiming system.



High Image Quality


The high performance IRay Vox detector and the advanced image processing create brilliant and sharp images.

Ultra Clear Mode

Built-in Ultraclear mode for bad weather such as heavy fog and raining, it will be more sensitive and get more details.

AMOLED Micro Display

High contrast AMOLED micro display with HD resolution offers crisp image and vivid colors. Display ensures excellent image quality and flawless performance even in freezing temperatures.



No Rezeroing Required and Quick Attached

With the special calibration to the camera, no rezeroing is required after attaching to the day scope. Clamp and Shoot, super simple to use.

Compact Size and Lightweight

Compact size and lightweight design do not influence the balance of the rifle significantly.



Familiar Precision

Front-mounted allows consistent shooting position and eye relief with an existing day rifle scope. Original design and precision technology ensure POI stability when attachment is in use. Users do not need to make any correction to position of day rifle scope's reticle when mounting Clip C Series.

Quick Transformation

Clip C series is a dual-use camera since it can be switched into a professional monocular with the standard delivered eyepiece in few seconds. It can be used as a thermal monocular for searching or as an attachment of day rifle scope for shooting.



Wireless Remote Control

Wireless remote control can be fixed near trigger which allows basic operations to be fulfilled easily.

Built-in Accelerometer And Digital Compass

Built-in accelerometer and digital compass improve accuracy by precisely identifying cant and angles. The Clip C series can indicate the direction and degree of lateral tilting. Wireless remote controller connected via bluetooth can be fixed near trigger which allows basic operations to be fulfilled easily.



Compass



Msensor



Bluetooth

Your Wise Choose with Clip C Series

Model	Clip CL42
Detector Parameters	
Packaging Type	Ceramic
Resolution	384×288

Pixel Pitch	17μm
NETD	≤50mK
Frame Rate	50Hz
Optical Parameters	
Objective Lens	42mm
Field of View	8.9°×6.7°
Magnification	Attachment:1× ; Monocular : 2.8×~11.2×
Diopter Adjustment	-5D~+5D
Detection Range (Target Size:1.7m×1.2m)	Detection : 2100m (2 pixels)
	Recognition : 700m (6 pixels)
Display	

Display Type	OLED
Display Resolution	1024×768
Additional Function	
E-Compass	✓
Accelerometer	✓
Bluetooth Remoter	✓
Accessory	M18 Handheld Eyepiece
Physical Parameters	
Battery	CR123×2
Battery Life (Max)	4h
Degrees of Protection	IP66

Weight (without batteries)	<420g
Dimension	154mm×61mm×58mm
Interface	M52×0.75
The data above are for reference only. Specifications in the marketed products shall prevail.	

Product consulting

* Message contents :



Mobile phone :

* Country :

* Product :

E-mail :

Submit

CONTACT US

Marketing Dept.Email:sales@infiray.com

HR Email:hr01@infiray.com

Sales Hotline:+86-400-998-3088

After sales hotline:+86-400-883-0800

Address:11th Guiyang Street, YEDA,Yantai 264006,P.R.China

IMAGERS

Thermal Monocular

Phone Thermal Camera

Car Thermal Camera

[Clip on Thermal Scope](#)

[Rico Thermal Scope](#)

[Tube Thermal Scope](#)

[Dual spectrum thermal imager](#)

[online monitring thermal camera](#)

MODULES

[Micro III Thermal Imaging Module](#)

[Mini Thermal Imaging Module](#)

[LT Temperature Measurement Module](#)

[FT Alarming Thermal Imaging Module](#)

[Phoenix Cooled MWIR Imaging Module](#)

APPLICATIONS

[Infrared Thermography](#)

[Security Thermal Camera](#)

[Night Vision](#)

[UAV Thermal Module](#)

[Smart Phone](#)

[Automotive Thermal Camera](#)

Follow Us :



