DAEHAN SENSOR



Digital Liquid Indicate with level controller

DFC - Series
Level Indicator with Relay Output

Product Name DFC - 4U - 2W





Table of Contents

1.	Introduction	3
2.	Specification	3
3.	Dimensiosns	4
4.	Wiring Connection	5
5.	Display Operation	6
6.	Check Point Before A/S	10

SPECIFICATIONS

Introduction

This DFC-4U-2W Series Level Controller gets signal from each point of the sensor installed in the tank and displays the level of the liquid in the tank as points.

Using a converter for 2-wire transmission, this changes contact signal to current.


LED display enables you to read the current status correctly and easily. This is designed to control two alarms and one of control which activates the connected pump.


In the mode of drainage, if it does not stop at the HIGH set-point, HIGH alarm turns on.

If it does not stop at the LOW set-point, LOW alarm turns on.

Specification


▶ Power Supply AC110V / 220V ±10%, 50/60Hz
▶ Operating Temperature · 0°C ~ 60°C
▶ Dimensions · 87mm (Wide) x 155mm (High) x 69mm (Deep)
▶ Material · Polycabonate & A.B.S
► Max. Switching Current Capacitor · 1250VA, 150W
► Max. Switching Volatge · 250VDC, 30VDC
► Max. Switching Current · 5A







Wiring Connection


Supply / Drain Selection












Display Operation


1. Low Level Display



When the liquid level goes Down to reach
the LOW/A point, the LOW/A indcator
turns on. At the same time, the LOW/A
contact signal activates the connected
buzzer and purmp.



2. High Level Display




When the liquid level goes Up to reach the HIGH/A point, the HIGH/A indcator turns on. At the same time, the HIGH/A contact signal activates the connected buzzer and purmp.



Display Operation


1. Supply Control "On" Level Display



When the liquid level goes Down to reach
the START point, the START indicator
turns on. At the same time, the START
contact signal activates the connected
pump.



2. Supply Control "Off" Level Display




When the liquid level goes up to reach
the STOP point, the STOP indicator turns
on. At the same time, the CONTROL
contact signal is not out and deactivates
the connected pump.



Display Operation


1. Drain Control "On" Level Display



When the liquid level goes Up to reach the START point, the START indicator turns on. At the same time, the START contact signal activates the connected pump.



2. Drain Control "Off" Level Display



When the liquid level goes Down to reach
the STOP point, the STOP indicator turns
on. At the same time, the CONTROL
contact signal is not out and deactivates
the connected pump.



Check & A/S

If you find any abnormal system during operation, please try to check below points.

- 1. Is the power connected to AC110V or AC220V correctly?
- 2. Is the wiring to the sensor made correctly?
- 3. Is the contact with the relay built up through correct sequence?
- 4. Is the current input from the sensor correct?
- 5. Is there any malfuction around the unit?

If the trouble still exists, please kindly contact below.

* Installation and operation manual is subject to change without prior notice for quality improvement.

Head Office

94-2, Yongdap-dong, Seongdong-gu, Seoul, Korea

R&D Office

2-71, Jeonong-dong, Dongdaemun-gu, Seoul, Korea

Tel: 02-2213-9888(代) Fax: 02-2245-3482

e.mail: master@dh34.com Domain: www.dh34.com